

# Loctite® Power Grab® Express Heavy Duty Installation Instructions:

ACOUSTIC PANELS (Fabric, Image, & AcoustiColor®)  
ACOUSTICOLOR SHAPES  
AUDIMUTE STRATA®  
ACOUSTIWOOD®, ACOUSTISTONE™, ACOUSTIFELT™  
TESSTILES

**Step 1:** Apply 2" diameter dabs of adhesive on a panel, no more than 2' apart.



**Step 2:** Press firmly into place and you're done!

