

Audimute® MultiDepth Panel Arrangement

Step 1



Layout your preferred panel arrangement on a horizontal surface. Record measurements for location of offset mounts and overall size of arrangement.

Step 2



Measure installation wall to find appropriate placement for center panel based off of overall size of arrangement from step 1.

Step 3



Place the top offset mounts for your center panel according to measurements from step 1.

Step 4



After installing the center panel, start placing your additional panels around it and marking the Z-Clip placements.

Step 5



You may have to remove your center panel to install Z-Clips for your additional panels that lie behind the center panel.

Step 6



Put center panel back in place and enjoy your new acoustic art arrangement.