

Paslode® Brad Nailer Installation Instructions:

ACOUSTIWOOD™ ACOUSTIC WOOD ALTERNATIVE PLANKS ACOUSTICOLOR® ACOUSTIC PANELS & SHAPES

Step 1: Attach the compatible foot to the brad nailer, then fasten panels in place with the brad nailer. Always use eye protection and follow Paslode's instructions for use.



Optional Step: When installing AcoustiWood Planks, a retractable utility knife and a T-square can be used to cut the planks as needed for an exact fit.



If you want to remove or move the panels, simply pull them off the wall and use pliers to pull out any nails that are left in the wall.

