
Audimute® TessaTiles





TESSATILES


Patterned after your style.

TessaTiles combine aesthetics with acoustic performance.
TessaTiles are a great echo absorber that are made with our eco-C-tex® eco-friendly absorption material. Choose from 11 different tiles or contact us to help you create you own pattern. These tiles were designed to work singularly as spot treatment or to be grouped together to cover a larger area.

TessaTiles are available in several standard color options, but we can also accommodate custom color requests.


Bring your wall art ideas to life by adding TessaTiles to any space. They are perfect for adding an artistic touch to any space in addition to promoting a positive acoustic environment. TessaTiles are great for commercial spaces and residential spaces a like.






TESSATILES

ELEVATION: TESSATILE 4 PACK GROUPING (Custom Sizes Available)



PLAN VIEW TESSATILE



TESSATILES: SPECIFICATIONS

CONTENT	P.E.T. 10% - 30%, Recycled Cotton 70% - 90%
COMPONENTS	1-1/2" and 1/2" Acoustic Substrate, AcoustiColor® Coating, Adhesive Hang Tab
DEPTH	2"
THICKNESS TOLERANCE	+-1/4"
SIZES & WEIGHTS	2' x 2' (5 lb), & Custom sizes available upon request.
FINISH OPTIONS	AcoustiColor® Coating
FACE STYLE	Dispersion, Polygon, Running Dashes, Wave, Chinese Lattice, Cellular, Triangle Lattice, Floral, Highways, Maze, Leaf Vein, Custom
APPLICATION	Indoor Walls
CUTTING / ALTERATIONS	N/A
INSTALLATION	Adhesive Hang Tab, Loctite® Power Grab® Express Heavy Duty
HANDLING / CARE	When handling make sure hands are clean and oil free. Vacuuming or light brushing is recommended to prevent dust and soil buildup.
STORAGE	Must be stored in a dry place. Delivery Packaging is not ideal for storage purposes. It is advised to place a polyethylene cover over the stack when packaging is removed, to reduce moisture absorption. It is recommended that product be stored horizontally. It is recommended that product should not be stacked. It is strongly recommended to avoid storage longer than 6 months. Do not allow water to come into direct contact with the material during storage. Store in a cool dry space 55°F - 85°F.
FIRE RATING	ASTM E84 Class A.
ACOUSTIC RATING	NRC: 0.55 - 0.95

TESSATILES: PATTERN OPTIONS

Find a pattern that matches your existing décor or select a pattern that will be the focal point in your space.

Bring your wall art ideas to life by adding TessaTiles to any space. They are perfect for adding an artistic touch to your home office space in addition to promoting a positive acoustic environment. TessaTiles are great for commercial spaces too! Build your acoustic design in high traffic areas to bring a designer look that helps to reduce the busy sounds of your space.


















Highways

Leaf Vein

Maze

Polygon

Floral







Running Dashes Triangle


Wave

TESSATILES: ACOUSTICOLOR® COATING OPTIONS

The possibilities are endless.

There are 1,000's of color options to choose from Sherwin-Williams' line of acoustical coatings. We can also match colors from other commercial paint manufacturers. With TessaTiles you have the opportunity to match the décor of any space. Our coated acoustic panels are made from recycled cotton and paper products which gives a unique textured finish.

NOTE: Color matching cannot be guaranteed across shipments from different orders and variation may be more pronounced beyond the normal commercial range.



TESSATILES: ACOUSTICOLOR® COATING OPTIONS

Add exceptional sound absorption, superior aesthetics, and design flexibility that reflects your individual personality and style with TessaTiles.


TessaTiles are lightweight and create a modern appearance combined with noise reduction and reverberation control. Stylish lines and soft shapes suspend horizontally from the ceiling and absorb sound across their entire surface for unequaled acoustical performance. Because TessaTiles are created using recycled materials, natural variations in texture and shading can occur.



TESSATILES: ACOUSTIC TESTING

TessaTiles Test Report

The test report quotes the frequency dependent sound absorption data as well as the single number ratings. Data taken from Test Report RAL-A17-297 conducted by Riverbank Acoustical Laboratories. Complete test results are available upon request.



FREQUENCY (HZ)

SAA = 0.52 - 0.97NRC = 0.55 - 0.95

Hang Tabs Installation Instructions:

ACOUSTIC PANELS (Fabric, Image, & AcoustiColor®) ACOUSTICOLOR & ACOUSTIFELT™ TILES & SHAPES TESSATILES

Hang tabs are made of durable plastic with an adhesive backing that adheres to the back of the panels, and is secured with two screws. The tabs are then used to mount panels to a wall using our Easy, Standard, or Stacked installation methods. Typically, two hang tabs are used per panel, however, larger panels may require more.

Items needed: Hang tabs with included screws, a level, a pencil, and a Phillips head screwdriver.



Please note: For the Standard & Stacked Hang Tabs installation methods, you will also need a measuring tape.

Step 1: Position a panel on the wall. Use a level on the top of the panel.




Step 2: Remove the level and lightly draw a line across the top of the panel with a pencil.



Easy Method:

Step 3: Screw the Walldog fasteners into the wall, just below the line. Make sure to leave a small 1/8" gap for the hang tab.



Step 4: Peel the wax backer off the hang tab, then place the tab over the screw on the wall with the sticky side facing out.





Easy Method Continued:

Step 5: Position the panel firmly into place on the wall and apply pressure to the locations of the hang tabs, so the hang tabs stick to the back of the panel.






Step 6: Remove the panel by lifting up and out from the keyholes on the tabs.




Easy Method Continued:

Step 7: Secure the hang tabs on the back of the panel with the small screws provided.



Step 8: Hang the panel on the wall, like you would a wall clock, sliding the keyholes over the screws and it will be positioned precisely where you want it.



Standard Method (measuring tape required):

Step 3 (see page 2 for steps 1 & 2): Peel the wax backer off the hang tabs, then place the hang tabs sticky side down on the back of the panel, and secure the tabs with the small screws provided.






Step 4: Measure the distance between the keyholes on the hang tabs and from the top of the keyholes to the top of the panel.



Standard Method Continued:

Step 5: Apply the same measurements taken in Step 4 to the wall, using the line created in Step 2 as a reference to the top of the panel. Mark the locations of where the keyholes will be on the wall with a pencil.






Step 6: Screw the Walldog fasteners into the wall, just below the line. Make sure to leave a small 1/8" gap for the hang tabs.



Standard Method Continued:

Step 7: Hang the panel on the wall, like you would a wall clock, sliding the keyholes over the screws.






Stacked Method (measuring tape required):

Step 3 (see page 2 for steps 1 & 2): Use Steps 1 & 2 for the first row only. For all panels except for the one(s) for the top row, peel the wax backer off the hang tabs, then place the hang tabs sticky side down on the back of the panel just above the top edge, and secure the tabs with the small screws provided.





For the panel(s) that will be used for the top row, install the hang tabs just below the top edge. Install the hang tabs with equal distances from the top edge of the panel(s).



Stacked Method Continued:

Step 4: Place the first panel for the bottom row on the wall, using the level line drawn in Step 2 as a reference to the top of the panel. Screw the Walldog fasteners into the wall through the top of the keyholes in the hang tabs.



Step 5 (optional): For additional panels before the top row, rest the panels on top of the lower row and repeat the instruction in the last sentence of Step 4.



Stacked Method Continued:

Step 6: For the panel(s) for the top row, measure the distance between the keyholes on the hang tabs and the distance from the bottom of the panel(s) to nearly the top of the keyholes on the tabs. Then, apply the same measurements to the wall and mark the locations of where the keyholes will be on the wall with a pencil.





Step 7: For the top panel(s), screw the Walldog fasteners into the wall and make sure to leave a small 1/8" gap for the hang tabs.



Stacked Method Continued:

Step 8: Hang the top row panel(s) on the wall, like you would a wall clock, sliding the keyholes over the screws.



Loctite® Power Grab® Express Heavy Duty Installation Instructions:

Step 1: Apply 2" diameter dabs of adhesive on a panel, no more than 2' apart.



Step 2: Press firmly into place and you're done!







Mitch Zlotnik

Founder & President of Audimute

Our founder Mitch Zlotnik loved his drums and respected his neighbors. So he invented a versatile sound absorption solution a musician could afford and a neighbor would love. Today our invention, eco-C-tex® is the key ingredient in a versatile suite of sound absorption and sound proofing solutions. Proudly made from 100% recycled materials, Audimute products are revolutionizing the way people experience work, worship, entertainment, and their home.

1.866.505.MUTE sales@audimute.com 9 am – 5 pm, Monday – Friday EST.