



Peacemaker[®] Sound Insulation

Typical Floor Installation Guide

UPON DELIVERY OF PRODUCT

1. VERIFY packing slip matches with product, order and quantity.
2. INSPECT delivered product thoroughly. Report any discrepancies of original order, product defects, etc. Please report any defects to Audimute prior to installation.
3. STORE product in clean, dry, environment with temperatures between 70° and 95° F.
4. READ all instructions, warranty and other disclaimers carefully and completely before starting installation.

Warning:

DO NOT use recycled rubber products with any petroleum based products. This includes solvents, adhesives or sealants. All substrates (especially new concrete) must be fully cured for 45 to 60 days prior to installing Peacemaker.

Introductory Note:

This installation guide is intended to provide the necessary information for the proper installation of Peacemaker. These instructions are believed to be based on accepted industry standards and are provided for informational use only. AUDIMUTE DOES NOT WARRANT ANY INSTALLATION PERFORMED PURSUANT TO THESE INSTRUCTIONS OR OTHERWISE AND SPECIFICALLY DISCLAIMS LIABILITY FOR ANY DIRECT OR INDIRECT PERSONAL INJURY, PROPERTY DAMAGE OR OTHER COSTS OR LOSSES RESULTING FROM INSTALLATION. Peacemaker should be installed by qualified and experienced personnel.

Guarantee:

Our 100% guarantee applies to all of our acoustic products when you contact us in advance of your purchase for our recommendations and expertise. Please give us a call first so that we can ensure you are purchasing the right product for your soundproofing application. We guarantee you'll be glad you spoke to an expert for your solution. We are even on call extended hours for your convenience!

Please note our 30 DAY RETURN POLICY* gives you plenty of time to consider your purchase. If for any reason you are not satisfied, you can return any item in its original condition and original packaging within 30 days of the date of shipment for a refund or exchange (Please Note: Restocking fees may be applied. Please contact us first to obtain a Return Authorization Number.)



MATERIALS NEEDED

Required:

1. Tape measure
2. Straight edge
3. White marker or chalk
4. Utility knife
5. 2" Peacemaker seam tape or foil seam tape (optional)
6. Drill or screw gun with mechanical fasteners

Alternative Fasteners:

1. 25" staples and caps, with power cap stapler roofing buttonkaps, at least 1" (ring shank nail with plastic cap)
- 1.5" coarse thread drywall screws, with fender washers

Recommended:

Acoustical caulk

Adhesive Options:

Any multi-purpose construction adhesive (such as Liquid Nails or PL)

Prep Work:

Trim rolls of Peacemaker only as needed. Peacemaker must reach room temperature to ensure secure, tight installation with minimal size fluctuation. Any sub-surface should be reasonably flat and free of holes or variances of more than 1/16".

1. Be certain the subfloor is clean, dry, smooth, level and structurally sound. Test floor for vapor drive in accordance with surface flooring manufacturer's recommended installation procedures. Generally, vapor drive should not exceed the industry standard of <3.0 lbs. per 1,000 square feet in 24 hours. If moisture exceeds flooring manufacturer's specifications, follow their installation procedures for moisture control.
2. Mechanical surface profiling is the preferred floor preparation method. It is the only acceptable preparation method where warranties are issued. Acid etching is not recommended. Mechanically profile the floor to medium-grit sandpaper texture. Remove curing and parting compounds and other surface hardeners and floor coatings in accordance with the surface flooring manufacturer's instructions.

Contact Us: 23945 Mercantile, Suite H Cleveland, OH 44122 Ph.: (866) 505-MUTE Fax: (866) 809-5018

Email: info@audimutesoundproofing.com www.audimutesoundproofing.com

✓ 100% Satisfaction Guaranteed ✓ Direct from Manufacturer ✓ Great Prices ✓ Exceptional Service



Peacemaker[®]

Sound Control Material



Typical Floor Installation Instructions

Concrete Floor Prep:

New concrete must be allowed to cure thoroughly prior to installation (45 to 60 days). If sealants are used, DO NOT use one with a petroleum base. Old concrete must be repaired and have joint sealants and fillers installed as necessary. All cracks or flaws should be filled in or repaired prior to covering with Peacemaker. Use patching materials as appropriate. The concrete surface must be thoroughly cleaned of dirt, dust, grease, or other foreign matter and allowed to dry completely before beginning installation.

Wood Base Prep:

Wood surfaces should be completely cleaned of dirt, dust, grease or other foreign matter and be completely dry prior to installation. Trapped moisture may rot the wood. Nails or other protrusions should be pounded down or removed, holes repaired, and surface variances repaired within the 1/16" acceptable variance level.

Additional Floor Installation Notes:

Some individuals leave Peacemaker exposed as the finished floor surface - although this method works, Peacemaker is not intended to be the finished floor surface and is most effective when sandwiched between two rigid structures, like joists and a subfloor, or a subfloor and a finished floor.

Instructions:

1. Measure the length and width of the floor to determine how much Peacemaker is needed.
2. Begin unrolling Peacemaker across the joists, starting in a corner of the room. Keep in mind that the fewer cuts you make, the more effective Peacemaker will be at blocking sound. If possible, unroll Peacemaker in the direction of the longest part of the room.
3. Fasten Peacemaker to the floor joists every two feet, making sure the material is lying flat and aligned parallel to the wall. This can be done using staples, button caps or screws.
4. Align seams to fit tightly next to each other. As you install each strip of Peacemaker, align the seams then tape them using a double layer of foil or vinyl seam tape. This will ensure a more airtight fit for maximum product performance.
5. Repeat process for each roll.
6. After all layers of Peacemaker are installed, apply acoustical caulk at all edges where Peacemaker meets the wall. (To create an airtight fit, which is essential to effectively block sound.)

